



CHANGING COLLECTION BAGS

WARNING: Empty the collection tank when necessary but also after each use (8 hours shift). Do not allow collected material to sit for extended periods of time. An excessive accumulation of collected material can create a dust ignition hazard.

To detach the collection bag from the suction inlet, **HOLD THE COLLAR** and gently pull it out from the suction inlet




DO NOT detach the collection bag by pulling on the bag itself as the collar could be torn apart from the bag material. Hold from the collar.



**READ THE INSTRUCTION MANUAL BEFORE OPERATING,
CLEANING OR SERVICING THE VACUUM CLEANER**

INSTALLING COLLECTION BAGS

Correct direction



Please do not install the bag in this direction

